


slurp

Expt 5

Routing Information Protocol

Aim: Configuring RIP routing protocol

Topology:



Procedure - place 3 generic routers & 2 generic PC's

- * Connect routers to PC with copper crossovers
- * Connect routers with serial DCE with clock symbol
- * place notes near the devices
- * set IP addresses for PC's & their subnet mask & default gateway
- * CLI of router 0 -> enable
 - > config
 - > interface fastEthernet 0/0
 - > IP address 10.0.0.10 255.0.0.0
 - > no shut
- * Connection should turn green
- * repeat for PC1 & router 2
- * open CLI of router 0
 - > enable
 - > config
 - > interface serial 2/0
 - > IP address 20.0.0.10 255.0.0.0
 - > encapsulation PPP
 - > clock rate 64000
 - > no shut

follow

* open CLI for router 1

→ enable

→ config

→ interface serial 2/0

→ ip address 20.0.0.20 255.0.0.0

→ encapsulation PPP

→ no shut

* Connection turns green

* → exit

→ show ip route

* open CLI of router 1

→ enable

→ config

→ interface serial 3/0

→ ip address 30.0.0.10 255.0.0.0

→ encapsulation PPP

→ clock rate 64000

→ no shut

→ exit

* open CLI of router 2

→ enable

→ config

→ interface serial 2/0

→ ip address 30.0.0.20 255.0.0.0

→ encapsulation PPP

→ no shut

* open CLI of router 1

→ exit

config # router RIP

config # router # network 10.0.0.0

config - router # network 20.0.0.0

config - router # exit

→ show ip route

* Similarly repeat for router 1 & router 2 with network
20.30 & 30.40

Sim mode:- Add sample PDU by selecting PC's & click
Auto capture

Real time mode:- Select PC0 go to command prompt &
select destⁿ address [ping 10.0.0.10] then other
addresses. finally ping PC2

Result:- PC > ping 10.0.0.10

Pinging 10.0.0.10 with 32 bytes of data

Reply from 10.0.0.10: bytes=32 time=0ms TTL=255
" " " " " "
" " " " " "
" " " " " "
"

PC > Ping 20.0.0.10

Pinging 20.0.0.10 with 32 bytes of data:

Reply from 20.0.0.10: bytes=32 time=0ms TTL=255
" " " " " "
" " " " " "
" " " " " "
"

PC > Ping 40.0.0.1

Pinging 40.0.0.1 with 32 bytes of data:

Reply from 40.0.0.1 bytes=32 time=2ms TTL=125
" " " " " 2ms "
" " " " " 1ms "
" " " " " 1ms "

Learnings : RIP is a protocol that routers can use to exchange network topology information. It is used in small to medium sized networks. A router sends the contents of its routing table to each adjacent router every 30s.